






PART NO.	DESCRIPTION
101	PHLP HD SCR M5-.8 X 8
102	LEADSCREW COVER
103	EXT RETAINING RING 14MM
104	CHANGE GEAR SPACER
105	SMALL GEAR
106	KEY 4 X 4 X 8
107	CHANGE GEAR SHAFT
108	PHLP HD SCR M4-.7 X 16
109	ADJUSTING DISC
110	SHAFT SUPPORT
111	TAPER PIN 6 X 26
112	PHLP HD SCR M5-.8 X 20
113	BOLT (WITH SHOULDER)
114	OIL CUP 6
115	BLOCK FOR SWITCH
116	PHLP HD SCR M4-.7 X 8
117	LEADSCREW SUPPORT L
118	PHLP HD SCR M4-.7 X 8
119	ROUND NUT
120	STEEL WASHER
121	PHLP HD SCR M5-.8 X 14
122	SWITCH LABEL
123	SHAFT COVER
124	BED

PART NO.	DESCRIPTION
125	HEX NUT M6-1.0
126	FLAT WASHER 6MM
127	HEX BOLT M6-1 X 10
128	SPLASH GUARD
129	PHLP SCR M8-1.25 X 15
130	FLAT WASHER 8MM
131	PHLP SCR M8-1.25 X 20
132	RACK
133	PHLP HD SCR M5-.8 X 12
134	LEADSCREW SUPPORT R
135	LONG LEADSCREW
136	ROLL PIN 4 X 25
137	SLEEVE JOINT
138	JOINT SHAFT
146	HEX BOLT M12-1.75 X 40
147	FLAT WASHER 12MM
148	KEY 4 X 4 X 16
154	PHLP HD SCR M4-.7 X 16
155	SMALL GEAR PROTECT
156	GREEN LAMP
157	FUSE BOX
158	FUSE
159	SELECTOR SWITCH




PART NO.	DESCRIPTION
201	PHLP HD SCR M5-.8 X 10
202	PHLP HD SCR M3-.5 X 14
203	POWER SWITCH W/STOP
204	PHLP HD SCR M5-.8 X 30
205	FWD/REV SWITCH
206	HEX NUT M5-0.8
207	FLAT WASHER 5MM
208	CONNECTOR
209	ROUND NUT M27-1.5
210	SPINDLE PULLEY
211	SPINDLE GEAR
212	OIL RING
213	PHLP HD SCR M5-.8 X 8
214	SPINDLE SPACER
215	BEARING 32007
216	SPINDLE BOX COVER
217	HEX NUT M4-0.7
218	PHLP HD SCR M4-.7 X 35
219	PIN SHAFT
220	BOX FOR MICRO SWITCH
221	HEAD STOCK BODY
222	FIXING NUT
223	ROTATABLE SPACER
224	KEY 4 X 4 X 40
225	SPINDLE
226	PHLP HD SCR M6-1 X 16


PART NO.	DESCRIPTION
227	FRONT BEARING COVER
228	LOCK WASHER 5MM
229	EXT TOOTH WASHER M5
230	PHLP HD SCR M5-0.8 X 16
231	SPINDLE CENTER MT3
232	3-JAW CHUCK D=125MM
233	EXT RETAINING RING 6MM
234	PHLP HD SCR M5-.8 X 12
235	PHLP SCR M10-1.5 X 25
236	PHLP HD SCR M5-.8 X 10
237	SUPPORT
238	LIMIT BLOCK
239	CHUCK GUARD
240	FIXING SUPPORT
241	SMALL SHAFT
242	COMPRESS SPRING
243	FLAT WASHER 6MM
244	HEX NUT M6-1.0
245	PLATE FOR SWITCHES
246	FLAT WASHER 10MM
247	PHLP HD SCR M5-.8 X 8
248	MICROSWITCH
249	3-JAW CHUCK FLANGE
250	HEX BOLT M8-1.25 X 30
251	PLUG BOLT
252	HEX NUT M10-1.5



PART NO.	DESCRIPTION
301	PHLP SCR M8-1.25 X 30
302	TAILSTOCK T-NUT
303	FLAT WASHER 12MM
304	HEX NUT M12-1.75
305	TAILSTOCK BODY
306	BEARING 51101
307	TAILSTOCK LEADSCREW
308	TAILSTOCK SLEEVE
309	TUBULAR CLAMP
310	FLAT WASHER 8MM
311	CLAMP BOLT
312	HANDLE
313	OIL CUP
314	T-TAPY FLAT KEY
315	PHLP HD SCR M6-1 X 16
316	PHLP HD SCR M5-.8 X 20
317	TAILSTOCK END COVER
318	CYLINDER PIN 4*30
319	SPRING BOW
320	HAND WHEEL
321	HANDLE BOLT
322	HANDLE SLEEVE
323	INDEX RING
324	SQ HD BOLT M12 X 100
325	TAILSTOCKCLAMP PLATE
326	BASE
327	ZERO POSITION LABEL
328	LABEL RIVET
329	INDICATE LABEL
330	TAILSTOCK CENTER MT2



PART NO.	DESCRIPTION
401	CUTTER REST BASE
402	CLAMP DISC
403	HEX BOLT M8-1.25 X 20
404	CUTTER REST DISC
405	CUTTER REST BOLT
406	HEX NUT M4-0.7
407	PHLP HD SCR M4-.7 X 20
408	PHLP HD SCR M4-.7 X 12
409	OIL CUP 10
410	FIXING PIN
411	SQUARE CUTTER REST
412	PHLP SCR M8-1.25 X 30
413	HANDLE
414	HANDLE BASE
415	HANDLE SPACER
416	SPRING 0.5 X 3.5 X 17
417	CUTTER REST CARRIAGE
418	PAD IRON GIB
419	CYLINDER PIN 3 X 10
420	CARRIAGE LEAD SCREW
421	KEY 3 X 3 X 10
422	OIL CUP 6
423	LEADSCREW SUPPORT
424	PHLP HD SCR M5-0.8 X 16
425	SPRING PLATE
426	HANDLE
427	HEX NUT M8-1.25
428	FLAT WASHER 8MM
429	CARRIAGE HANDWHEEL
430	INDEX RING
431	PHLP HD SCR M6-1 X 16
432	CYLINDER PIN 4 X 16




PART NO. DESCRIPTION


501	HAND WHEEL
502	OIL CUP 6
503	KEY 4 X 4 X 12
504	ROUND NUT
505	PHLP HD SCR M3-.5 X 6
506	OIL-STOPPING FELT
507	PHLP HD SCR M6-1.0 X 35
508	SADDLE LEADSCREW
509	SADDLE
510	PHLP HD SCR M4-.7 X 12
511	CLEARANCE NUT
512	PHLP HD SCR M3-.5 X 12
513	HEX NUT M5-0.8
514	PHLP HD SCR M5-.8 X 26
515	PAD IRON GIB
516	CROSS SLIDE
517	PHLP HD SCR M5-.8 X 10
518	CROSS SLIDE SPACER
519	PHLP SCR M8-1.25 X 10
520	GIB STRIP

PART NO. DESCRIPTION

521	REAR-CLAMP PLATE
522	PHLP HD SCR M4-.7 X 16
523	PHLP HD SCR M5-.8 X 16
524	HEX NUT M4-0.7
525	PHLP SCR M8-1.25 X 20
526	PHLP HD SCR M5-.8 X 20
527	OIL-STOPPING FELT
528	PROTECTING PANEL
529	PROTECTING PANEL
530	FRONT-CLAMP PLATE
531	BRAKING PLATE
532	LEADSCREW SUPPORT
533	FLAT WASHER 6MM
534	HANDLE BOLT
535	HEX BOLT M6-1 X 20
536	HANDLE SLEEVE
537	BEARING 8101
538	SPRING PLATE
539	INDEX RING
542	ROLL PIN 6 X 45




PART NO.	DESCRIPTION
601	HANDLE
602	PHLP HD SCR M6-1 X 8
603	COMPRESS SPRING
604	STEEL BALL 5
605	HANDLE SEAT
606	PHLP HD SCR M6-1 X 16
607	PHLP HD SCR M4-.7 X 10
608	SHAFT SLEEVE
609	APRON BODY
610	HANDLE BOLT
611	HANDLE SLEEVE
612	HAND WHEEL
613	SPRING PLATE
614	INDEX RING
615	SMALL SHAFT SLEEVE
616	SPRING PIN 4 X 30
617	SMALL GEAR SHAFT
618	SHAFT SLEEVE
619	GEAR
620	PHLP HD SCR M4-.7 X 8
621	KEY 5 X 5 X 10
622	GEAR SHAFT
623	PHLP HD SCR M5-.8 X 16
624	ROLL PIN 4 X 22
625	HALF NUT BASE
626	ROLL PIN 5 X 12
627	ROLL PIN 3 X 20
628	HALF NUT
629	SLOTTED DISC
630	ROTATING SHAFT
631	SHAFT SLEEVE
632	MOVING PLATE
633	PHLP HD SCR M4-.7 X 8



PART NO.	DESCRIPTION
801	GEAR Z:72
802	GEAR Z:70
803	GEAR Z:68
804	GEAR Z:66
805	GEAR Z:60
806	GEAR Z:50
807	GEAR Z:48
808	GEAR Z:45
809	GEAR Z:90
810	WASHER
811	KNURLING BOLT
812	GEAR BOX COVER
813	GEAR Z:25
814	SCREW M5 X16
815	BOLT
816	NUT M12
817	OIL CUP 6
818	GEAR Z:80
819	GEAR Z:33
820	OPEN WASHER
821	BEARING 6001
822	INTERMEDIATE GEAR Z:40
823	CHECK RING 12
824	WASHER

PART NO.	DESCRIPTION
825	FIXED SHAFT BOLT
826	WASHER
827	GEAR BOX SUPPORT PLATE
828	GEAR Z:40
829	WASHER 8
830	BOLT M8 X 16
831	SLIDING BEARING
832	WASHER
833	GEAR REST
834	SQUARE NUT
835	SCREW M6 X 35
836	KEY 4 X 16
837	SCREW M4 X16
838	MICRO SWITCH
839	SCREW M4 X 30
840	NUT M4
841	LIMITED PLATE
842	MICRO SWITCH'S BOX
843	MAIN LABEL
844	CHANGING GEAR LABEL
849	HEX NUT M4-.7
850	PHILIP HD SCR M6-1.0 X 4
851	HINGE



PART NO.	DESCRIPTION
901	HEX BOLT M8-1.25 X 30
902	FLAT WASHER 8MM
903	AC MOTOR
904	KEY 5 X 5 X 40
905	MOTOR SHAFT SPACER
906	DRIVE PULLEY
907	KEYWAY SHAFT SPACER
908	MOTOR PULLEY
909	CHECK RING
910	PHLP HD SCR M6-1.0 X 30
911	OIL CUP 6
912	GREAT WASHER
913	COUNTER PULLEY
914	SLIDE BEARING
915	ARM SHAFT
916	BEARING ARBOR
917	TENSION PULLEY
918	BEARING 6001
919	SPACER
920	LOCK WASHER 6MM
921	EXT RETAINING RING 12MM
922	EXT RETAINING RING 28MM
923	PIVOT
924	PIVOT SPACER

PART NO.	DESCRIPTION
925	FLAT WASHER 10MM.
926	HEX NUT M10-1.5
927	PHLP HD SCR M3-.5 X 14
928	HEX BOLT M8-1.25 X 25
929	PHLP HD SCR M5-.8 X 8
930	FAN-SUPPORT
931	ADJ SLOT SPACER
932	PHLP HD SCR M6-1.0 X 35
933	HEX BOLT M10-1.5 X 25
934	HEX NUT M5-0.8
935	PULLEY SUPPORT
936	MOTOR COVER
937	PHLP HD SCR M6-1 X 12
938	ARM SHAFT NUT
939	SOCKET OUTLET
940	SUPPORT SPACER
941	PHLP HD SCR M3-.5 X 6
942	ELECTRIC TOP COVER
943	LOCK WASHER 8MM
944	TIMING BELT 1.5 X 124 X 15
945	V-BELT M-30 3L300
946	HEX NUT M5-0.8
947	MAIN POWER SOCKET