


# Super X1LP Parts Diagram & List



NO.	Description	QTY
1	Column	1
2	Screw M8x35	4
3	Spring washer M8	4
4	Washer	4
5	Pin 6X26	2
6	Bed	1
7	Screw nut	1
8	Screw M6*25	2
9	Cross wedge	1
10	Wedge	1
11	Headless set screw	8
12	Nut M4	8
13	Screw base	2
14	Label	2
15	Dial	2
16	Damp Spring	2
17	Key 3x10	3
18	Screw M6 x 20	4
19	Hand wheel	2
20	Screw Nut	1
21	Y-Axis Feed Screw	1
22	Screw M6 x 14	4
23	Headless set screw	4
24	Handle Bolt	3
25	Handle Sleeve	3
26	Top Nut M6	3
27	Washer	3
28	Rivet	8
29	Screw M4 x 20	2
30	Base	1
31	Worktable	1
32	X-Axis Feed Screw	1
33	Brushless Motor	1
34	Support for PC Board	1
35	Switch Panel	1
36	PC Board	1
37	Countersunk Screw	4
38	LCD	1
39	Fuseholder	1
40	Power Cable	1
41	Cable Joint	1
42	Emergency Stop Button	1
43	Forward & Reverse Switch	1
44	Potentiometer Knob	1
45	Electricity label	1

NO.	Description	QTY
46	Potentiometer X1	1
47	Small phillips head screw	4
48	Tapping screw	8
49	Small phillips head screw	3
50	Lock washer	3
51	Spring washer M5	3
52	Baffle	1
53	Electromagnetic Switch	1
54	Countersunk Screw	2
55	Nut M4	2
56	Circlip	2
57	Spring Seat Ring	1
58	Sleeve Support Plate	1
59	Spring Washer M6	2
60	Joint screw	1
61	Adjust Screw	1
62	Washer	1
63	Nut M10	1
64	Screw M8 x 50	1
65	Dial	1
66	Screw M5 x 8	2
67	Spring Pin 3 x 12	2
68	Long Handle Sleeve	1
69	Pin 6x26	2
70	Screw M6 x 20	4
71	Z-Axis Lifting Screw	1
72	Label	2
73	Headless set screw	1
74	Worm base	1
75	Screw M5 x 20	1
76	Helical gear	1
77	Spacing ring	1
78	Pin B 3 x 12	1
79	Joint Label	1
80	Pin B 3 x 18	1
81	Washer	1
82	Screw Support	1
83	Wedge	1
84	Handle	1
85	Headless set screw	4
86	Nut M4	4
87	Screw M5 x 12	7
88	Washer	7
89	Small phillips head screw	5
90	Small phillips head screw	4

NO.	Description	QTY
91	Worm Shaft	1
92	Dial Ring	1
93	Hand wheel	1
94	Spindle Seat	1
97	Damp Spring	1
99	Support	1
100	Spindle Sleeve	1
101	Joint shaft	1
102	Handle Shaft	1
103	Gear Shaft	1
104	Socket set screw	1
105	Compression Spring	1
106	Dust Cover	1
107	Ball Bearing	1
108	Lock Washer	1
109	Round Nut M20x1.5	1
110	Ball Bearing	1
111	Spindle Pulley	1
112	Motor Pulley	1
113	Motor Connecting Plate	1
114	Key 4x28	1
115	Circlip	1
116	Circlip	1
117	Timing belt	1
118	Baseplate	1
119	Countersunk Screw	4
120	Shield	1
121	Back Cover	1
122	Key 3x25	1
123	Small phillips head screw	3
124	MT2 Spindle	1
125	Drawbar	1
126	Protective Sleeve	1
127	Drill Chuck Arbor	1
128	Cushion	1
129	Splash Guard	1
130	Washer	2
131	Screw M4 x 14	2
132	Foot	4
133	Screw	1
134	Washer	1
135	Big Hand Wheel	1
136	Key 4x12	2
137	Joint Shaft	1
138	Ball Thrust Bearing	1

NO.	Description	QTY
139	Bearing Block	1
140	Ball Bearing	1
141	Socket set screw	2
142	Straight Bevel Gear	1
143	Cover	1
144	Screw M4x8	1
145	Screw	1
146	Washer	1
147	Straight Bevel Gear	1
148	Needle Roller Thrust Bearing	1
149	Screw M4x12	1
150	Connection Plate	1